

EVERCARETM-TREATED FLOORS TREATING HEAVILY DAMAGED AREAS

Mipolam Troplan / Cosmo / Elegance / Accord / Esprit / Symbioz / Biostyl



Damp sweeping equipment

Flexible mop preferably fitted with disposable, antistatic and/or pre-impregnated gauze strips





Reconditioning varnish application equipment

Mechanical cleaning disk 3M (or equivalent) colour disks

This reconditioning protocol can be applied to a defined area or to the entire room. In any case, isolate the area for 48 hours (to allow the varnish to cross-link).

	Equipment used	Cleaning products	Cleaning methods
Preparation of the floor Mechanical cleaning		Alkaline detergent	 Damp sweeping Mechanical washing with blue disk at 300-450 rpm (with water recovery)
Reconditioning Manual application	Por	Reconditioning varnish	 Apply a first coat of varnish with a brush to the most damaged areas (scratches), followed by application with a medium-length roller (≈120g/m²) on the entire area to be reconditioned. Leave to dry for 48 hours.
Daily cleaning	No change, follow the care protocol as recommended by Gerflor for each area		
Deep cleaning	No change, follow the care protocol as recommended by Gerflor for each area		

To offer you the best results in terms of hygiene and appearance, **Gerflor recommends that you use neutral and alkaline detergents with high wetting power** (complete spreading and cleaning of the entire floor surface).

Here is a non-exhaustive list of products recommended by the main manufacturers:				
KIEHL: Profloor*, RS Nett** TANA: Green care SR15*, Floor Cleaner S*, Clean Fresh*, Difotan*, Clean Extreme*, Innomat**	ECOLAB: Brial Clean S* ROCHEX: Polystar*, Roctonic** BUZIL: HC 43** DrSCHUTZ: PU Reiniger**	DIVERSEY: Asset* DREITURM: Multinetzer*, Goldreif (green)*, Goldreif (blue)*, Linorein**, D1 Neu**		
*Neutral / **Alkaline				
Reconditioning varnish: BLANCHON: Intensiv Ultra Mat	DrSCHUTZ: Super PU Siegel extra matt, Super PU Siegel Seidenmatt	RZ REINIGUNGS / PFLEGESYSTEME GmbH: Turbo Protect Zero Extramatt		